

# CHAPTER 4

## Dispersion in optical fibers

Dominique PAGNOUX




With the support of the  
Erasmus+ Programme  
of the European Union



## DEFINITION AND CAUSES OF DISPERSION IN OPTICAL FIBERS

**DISPERSION** : linear phenomenon resulting in a change (generally an increase) of the duration of a pulse when propagating in a fiber



3 causes of dispersion :

- intermodal dispersion (in multimode regime)  $\rightarrow D_i$
- chromatic dispersion  $\rightarrow D_c$
- polarization mode dispersion  $\rightarrow \text{PMD}$




\* In the multimode regime :  $D_i \gg D_c$  of each mode  $\gg$  PMD of each mode

$\rightarrow D_c$  and PMD are neglected

\* In the single mode régime :  $D_i = 0$


- $\rightarrow$  - if  $D_c$  of the fundamental mode  $\gg$  PMD (usual case)  $\rightarrow D_c$  only is taken into account and PMD is neglected
- si  $D_c$  of the fundamental mode  $\sim 0 \rightarrow$  PMD must be taken onto account (for very high bit rate transmissions)

## INTERMODALE DISPERSION



- due to the fact that each excited mode has its own group velocity, different from that of the others
- $D_1$  = pulse broadening per unit of length along which light propagates (ns/km)

# INTERMODALE DISPERSION



→ due to the fact that each excited mode has its own group velocity, different from that of the others

→  $D_1$  = pulse broadening per unit of length along which light propagates (ns/km)

group delay:  $t_g = \frac{L}{v_g}$

For a step index fiber →

$v_g \approx \frac{c}{n_1} \sin i$

ray 1 →  $\sin i = 1 \rightarrow v_g \approx \frac{c}{n_1} \rightarrow t_{g1} \approx \frac{L}{c} n_1$

ray 2 →  $\sin i_{\min} = \frac{n_2}{n_1} \rightarrow v_g \approx \frac{c}{n_1} \frac{n_2}{n_1} \rightarrow t_{g2} \approx \frac{L}{c} \frac{n_1^2}{n_2}$

$\Delta t_g = \tau = t_{g2} - t_{g1}$

$\approx \frac{L}{c} n_1 \left( \frac{n_1}{n_2} - 1 \right) \approx \frac{L}{c} n_1 \left( \frac{n_1 - n_2}{n_2} \right)$

With  $\Delta = \left( \frac{n_1^2 - n_2^2}{2n_1^2} \right) = \frac{(n_1 + n_2)(n_1 - n_2)}{2n_1^2} \approx \frac{2n_1(n_1 - n_2)}{2n_1^2} \approx \frac{n_1 - n_2}{n_1}$

$\tau = \frac{L}{c} n_1 \Delta$

(step index fiber)

## INTERMODALE DISPERSION (step index fiber)


Definition :

$$D_I \triangleq \frac{\tau}{L} = \frac{n_1 \cdot \Delta}{c} \quad (\text{en ns/km})$$

(reminder :  $\tau = \frac{L}{c} n_1 \Delta$ )

Modulation bandwidth, for a fiber of length L :  **$B=1/\tau$**  (generally expressed in MHz)

**$B.L = B_L = L/\tau = 1/D_I = \text{constant}$**  (generally expressed in MHz.km)



# INTERMODALE DISPERSION (step index fiber)

Définition :

$$D_I \triangleq \frac{\tau}{L} = \frac{n_1 \cdot \Delta}{c} \quad (\text{en ns/km})$$

(reminder :  $\tau = \frac{L}{c} n_1 \Delta$ )

Modulation bandwidth, for a fiber of length L : **B=1/τ** (generally expressed in MHz)

B.L = **B<sub>L</sub> = L/τ = 1/D<sub>I</sub> = constant** (generally expressed in MHz.km)

Example :



*λ ≈ 0.8 μm*

→ **Step index fiber, length L= 3km with n1 = 1,465 and n2 =1,45**

$$\tau = 3 \cdot \frac{1}{3 \cdot 10^5} \cdot 1,465 \cdot \left( \frac{1,465-1,45}{1,45} \right) = 1,52 \cdot 10^{-7} s = \underline{\underline{152 \text{ ns}}}$$

$$B = \frac{1}{\tau} = \frac{1}{152 \cdot 10^{-9}} = 6,58 \cdot 10^6 \text{ Hz} = 6,58 \text{ MHz}$$

$$B_L = \frac{1}{D_I} = \frac{1}{51 \cdot 10^{-9}} \approx 20 \cdot 10^6 \text{ Hz.km} \approx \underline{\underline{20 \text{ MHz.km}}}$$


**Optimized graded index fiber**

$$\tau' = \tau/100$$

$$B' = 100 \cdot B$$

$$\underline{B'_L = 100 \cdot B_L}$$

# CHROMATIC DISPERSION



$\Delta\lambda = \lambda^2 \cdot \Delta\nu / c$   
 where  $\Delta\nu$  = spectral bandwidth of the pulse with  $\Delta t$ .  $\Delta\nu = cte \sim 1$

if  $\Delta t = 10 \text{ ps}$  with  $\lambda_0 = 1 \mu\text{m}$



$$\Delta\lambda = \frac{(10^{-6})^2}{3 \cdot 10^8} \times \frac{1}{10 \cdot 10^{-12}} = 3 \cdot 10^{-10} \text{ m} = 0.3 \text{ nm} \quad (\text{with } \Delta t \cdot \Delta\nu = 1)$$

causes of chromatic dispersion :

- dispersive material  $\rightarrow n=f(\lambda) \rightarrow v_\phi = c/n = f(\lambda) \rightarrow v_g = f(\lambda) \rightarrow$  **material dispersion ( $D_{\text{mat}}$ )**
- when the wave is guided,  $\beta = f(V) = f(\omega) \rightarrow v_g = d\omega/d\beta = f(\lambda) \rightarrow$  **guide dispersion ( $D_{\text{gui}}$ )**

In first approximation :  $D_c \approx D_{\text{mat}} + D_{\text{gui}}$

# CHROMATIC DISPERSION



Definition :

$$D_c = \frac{\tau}{L \cdot \Delta\lambda}$$

*ps*



*km*

*nm*

expressed in ps/(nm.km)




# CHROMATIC DISPERSION



Definition :

$$D_c = \frac{\tau}{L \cdot \Delta\lambda}$$

expressed in ps/(nm.km)



$$\tau = |t_g(\lambda_2) - t_g(\lambda_1)| \approx \frac{dt_g}{d\lambda} \Delta\lambda$$




$$D_c = \frac{1}{L} \frac{dt_g}{d\lambda}$$

# CHROMATIC DISPERSION

$$D_c = \frac{1}{L} \frac{dt_g}{d\lambda}$$

$$D_c = \frac{t_{gR} - t_{gB}}{L (\lambda_R - \lambda_B)} \quad \text{en ps/(nm.km)}$$

*R → red → long wavelengths.  
B → blue → short*



**CHROMATIC DISPERSION : remarks**

$$v_g = \frac{d\omega}{d\beta}$$

$$D_c = \frac{1}{L} \frac{dt_g}{d\lambda} = \frac{1}{L} \frac{d}{d\lambda} \left( \frac{L}{v_g} \right) = \frac{d}{d\lambda} \left( \frac{d\beta}{d\omega} \right) = \frac{d}{d\omega} \left( \frac{d\beta}{d\omega} \right) \cdot \frac{d\omega}{d\lambda} = - \frac{2\pi c}{\lambda^2} \frac{d^2\beta}{d\omega^2}$$

- the dispersion curve  $\beta=f(\omega)$  allows to calculate the chromatic dispersion (taking into account the actual values  $n_1(\lambda)$  and  $n_2(\lambda)$  at each wavelength)

**CHROMATIC DISPERSION : remarks**

$$\rightarrow D_c = \frac{1}{L} \frac{dt_g}{d\lambda} = \frac{1}{L} \frac{d}{d\lambda} \left( \frac{L}{v_g} \right) = \frac{d}{d\lambda} \left( \frac{d\beta}{d\omega} \right) = \frac{d}{d\omega} \left( \frac{d\beta}{d\omega} \right) \cdot \frac{d\omega}{d\lambda} = - \frac{2\pi c}{\lambda^2} \frac{d^2\beta}{d\omega^2}$$

→ the dispersion curve  $\beta=f(\omega)$  allows calculating the chromatic dispersion (taking into account the actual values  $n_1(\lambda)$  and  $n_2(\lambda)$  at each wavelength)

$$e^{j(\omega t - \beta z)}$$

Taylor expansion of the spectral phase of the guided wave :

$$\varphi(\omega) = \beta L = \beta(\omega_0) \cdot L + L \cdot \frac{d\beta}{d\omega} (\omega - \omega_0) + \frac{L}{2} \frac{d^2\beta}{d\omega^2} (\omega - \omega_0)^2 + \dots$$

out of the "guided optics" community,  $\frac{d^2\beta}{d\omega^2}$  is often called "group velocity dispersion"

→ inappropriate denomination and risk of confusion with  $D_c$

in fact  $\frac{d^2\beta}{d\omega^2}$  is proportional to the dispersion of group delay



## CALCULATION OF THE MATERIAL DISPERSION

→ plane wave (= propagating wave NOT GUIDED)

→ dispersive propagation medium :  $n_1 = f(\lambda)$

$$t_g = t_{mat} = \frac{L}{\check{v}_g} = \frac{L}{c} N_g = \frac{L}{c} \left( n_1 - \lambda \frac{dn_1}{d\lambda} \right)$$

$$v_g = \frac{c}{N_g} \quad \overset{1}{N_g} = n_1 - \lambda \frac{dn_1}{d\lambda}$$

## CALCULATION OF THE MATERIAL DISPERSION

→ plane wave (= propagating wave NOT GUIDED)

→ dispersive propagation medium :  $n_1 = f(\lambda)$

$$t_g = t_{mat} = \frac{L}{v_g} = \frac{L}{c} N_g = \frac{L}{c} \left( n_1 - \lambda \frac{dn_1}{d\lambda} \right)$$

$$\tau_{mat} = \Delta t_g = \frac{dt_{mat}}{d\lambda} \Delta\lambda = \frac{L\Delta\lambda}{c} \frac{d}{d\lambda} \left( n_1 - \lambda \frac{dn_1}{d\lambda} \right)$$

$$= \frac{L}{c} \Delta\lambda \cdot \left( \frac{dn_1}{d\lambda} - \left( 1 \times \frac{dn_1}{d\lambda} + \lambda \frac{d^2 n_1}{d\lambda^2} \right) \right)$$

$$= -\frac{\lambda L}{c} \Delta\lambda \cdot \frac{d^2 n_1}{d\lambda^2} //$$

## CALCULATION OF THE MATERIAL DISPERSION

→ plane wave (= propagating wave NOT GUIDED)

→ dispersive propagation medium :  $n_1 = f(\lambda)$

$$t_g = t_{mat} = \frac{L}{v_g} = \frac{L}{c} N_g = \frac{L}{c} \left( n_1 - \lambda \frac{dn_1}{d\lambda} \right)$$

$$\tau_{mat} = \Delta t_g = \frac{dt_{mat}}{d\lambda} \Delta\lambda = \frac{L\Delta\lambda}{c} \frac{d}{d\lambda} \left( n_1 - \lambda \frac{dn_1}{d\lambda} \right)$$

$$= \frac{L}{c} \Delta\lambda \cdot \left( \frac{dn_1}{d\lambda} - \left( 1 \times \frac{dn_1}{d\lambda} + \lambda \frac{d^2 n_1}{d\lambda^2} \right) \right)$$


$$= -\frac{\lambda L}{c} \Delta\lambda \cdot \frac{d^2 n_1}{d\lambda^2}$$

$$D_{mat} = \frac{\tau_{mat}}{L \cdot \Delta\lambda} = -\frac{\lambda}{c} \frac{d^2 n_1}{d\lambda^2}$$

# MATERIAL DISPERSION

$$\underline{D_{mat}} = -\frac{\lambda}{c} \frac{d^2 n_1}{d\lambda^2}$$

↑



For pure silica :

$$\begin{aligned} B_1 &= 0.696166300 \\ B_2 &= 0.407942600 \\ B_3 &= 0.897479400 \\ C_1 &= 4.67914826 \times 10^{-3} \mu\text{m}^2 \\ C_2 &= 1.35120631 \times 10^{-2} \mu\text{m}^2 \\ C_3 &= 97.9340025 \mu\text{m}^2 \end{aligned}$$



↑

$$n(\text{SiO}_2) = f(\lambda)$$





# MATERIAL DISPERSION

$$D_{mat} = -\frac{\lambda}{c} \underbrace{\frac{d^2 n_1}{d\lambda^2}}$$





# MATERIAL DISPERSION


$$D_{mat} = -\frac{\lambda}{c} \frac{d^2 n_1}{d\lambda^2}$$




# MATERIAL DISPERSION



## MATERIAL DISPERSION



example let us consider a beam from a laser diode emitting at 850nm, with  $\Delta\lambda = 40\text{nm}$ , launched in a fiber with a length  $L = 2\text{km}$



$$D_{mat} = -75\text{ps}/(\text{nm.km})$$




$$\tau_{mat} = L \cdot \Delta\lambda \cdot |D_{mat}|$$

$$= 2 \times 40 \times 75 = 6000\text{ps} = \underline{\underline{6\text{ns}}}$$

# CALCULATION OF THE GUIDE DISPERSION

→ guided wave

→ non dispersive propagation medium  $\Rightarrow \frac{dn_1}{d\lambda} = 0 ; \frac{dn_2}{d\lambda} = 0 ; \frac{d\Delta}{d\lambda} = 0$



$v_g = \frac{d\omega}{d\beta}$  et  $t_g = \frac{L}{v_g} = L \frac{d\beta}{d\omega} = \frac{L}{c} \frac{d\beta}{dk_0}$  (car  $\omega = k_0 \cdot c$ )

( Goal : express  $t_g$  as a function of  $B$  and  $V$  (→ allowing to exploit the dispersion curves  $B=f(V)$  )

One easily shows that :  $\beta = k_0 [n_2 + n_1 \Delta B]$


$k_0 = \frac{V}{a \cdot n_1 \sqrt{2\Delta}}$

$$t_g = t_{gui} = \frac{L}{c} \left[ n_2 + n_1 \Delta \frac{d(VB)}{dV} \right]$$

see the development of the calculations in [pdf pages 10 et 11](#)

## CALCULATION OF THE GUIDE DISPERSION

$$t_{gui} = \frac{L}{c} \left[ n_2 + n_1 \Delta \left[ \frac{d(VB)}{dV} \right] \right]$$



## CALCULATION OF THE GUIDE DISPERSION

temporal broadening :  $\rightarrow \tau_{gui} = \Delta t_{gui} = \frac{dt_{gui}}{d\lambda} \Delta\lambda$  (see slide number 9)


Dispersion due to guiding effect :  $D_{gui} = \frac{\tau_{gui}}{L \cdot \Delta\lambda}$

$$\rightarrow t_{gui} = \frac{L}{c} \left[ n_2 + n_1 \Delta \frac{d(VB)}{dV} \right]$$


resulting in :

$$D_{gui} = - \frac{n_1 \Delta}{c \lambda} V \frac{d^2(VB)}{dV^2}$$

(see the development of the calculations in pdf page 12)



# CALCULATION OF THE GUIDE DISPERSION



1.91

$$D_{gui} = - \frac{n_1 \Delta}{c \lambda} V \frac{d^2(VB)}{dV^2}$$

Example: case of a fiber with

$a = 4,5\mu m$   ~~$NA = 0,105$~~   $n_1 = 1,46$

à  $\lambda = 1,55\mu m$

$\Delta = \frac{NA^2}{2n_1^2} = 2,83 \cdot 10^{-3}$

$V = \frac{2\pi}{\lambda} a \sqrt{n_1^2 - n_2^2} = 1,91$


$V \frac{d^2(VB)}{dV^2} \approx 0,6$

$$D_{gui} = - \frac{1,46 \times 2,83 \cdot 10^{-3}}{3 \cdot 10^8 \times 1,55 \cdot 10^{-6}} \times 0,6 = - 510^{-6} s / (m.m) = - 5ps / (nm.km)$$




## CURVES OF THE CHROMATIC DISPERSION versus WAVELENGTH

Example with a step index fiber :  $n_1 = 1.46$      $n_2 = 1.455$      $a = 4 \mu\text{m}$




## CURVES OF THE CHROMATIC DISPERSION versus WAVELENGTH

Example with a step index fiber :  $n_1 = 1.46$      $n_2 = 1.455$      $a = 4 \mu\text{m}$




## CURVES OF THE CHROMATIC DISPERSION versus WAVELENGTH

Example with a step index fiber :  $n_1 = 1.46$      $n_2 = 1.455$      $a = 4 \mu\text{m}$



# CURVES OF THE CHROMATIC DISPERSION VERSUS WAVELENGTH



## How can we change the chromatic dispersion of an optical fiber ?

→ By changing the material dispersion ???? → no

→ By changing the dispersion of the guide !!!

⇒ Working with higher order modes

⇒ Working in the single mod regime, but with a fiber having a modified index profile

- multicladd fibers ("DS fibers", "DF fibers...")
- Air silica microstructured optical fibers (MOFs so called "PCFs")
- Bragg fibers or photonic bandgap fibers

# HOW CAN WE CHANGE THE DISPERSION OF THE GUIDE ?


$$D_g = - \frac{1}{\pi^2 n_2 c w_0^2} \left( \frac{\lambda}{w_0} \frac{dw_0}{d\lambda} - \frac{1}{2} \right)$$

Pierre Sansonetti, Elect. Letters, vol 18, n°15, pp 647-648 (1982)




$$\lambda_1 < \lambda_2 < \lambda_3$$





If the field significantly spreads in the cladding when  $\lambda \nearrow$



If the extension of the field do not change when  $\lambda \nearrow$











# DISPERSION SHIFTED FIBERS : MULTICLAD FIBERS




$$D = - \frac{\lambda}{c} \frac{d^2 n_e}{d\lambda^2}$$

# DISPERSION SHIFTED FIBERS : A LARGE VARIETY OF INDEX PROFILES




## DISPERSION SHIFTED OR FLATTENED FIBERS





## DISPERSION SHIFTED OR FLATTENED FIBERS





(b)

Optical Fiber communications, 3<sup>rd</sup> ed., G. Keiser, McGrawHill, 2000


## OTHER KINDS OF FIBERS FOR THE MANAGEMENT OF THE DISPERSION (1)

\* fibers with  $D_g \ll 0$  (compensating fibers)




index profile

JL Auguste et al.  
Optical fiber technology  
Vol. 24, issue 1, pp. 442- (2006)



Distribution of the field  
versus wavelength




measured chromatic dispersion



## OTHER KINDS OF FIBERS FOR THE MANAGEMENT OF THE DISPERSION (2)

\* fibers with  $D_g > 0$  at short wavelengths

→ Bragg Fibers




→ Hollow core photonic crystal fibers




## OTHER KINDS OF FIBERS FOR THE MANAGEMENT OF THE DISPERSION (3)

### \* fibers with Dg specially managed for particular applications

→ Air silica microstructured optical fibers :




diameter of holes :  $d$   
pitch :  $\Lambda$



$d = 0,6\mu\text{m}$   $\Lambda = 2,6\mu\text{m}$




flattened dispersion  
1100 nm – 1600 nm



$d = 1,9\mu\text{m}$   $\Lambda = 2,3\mu\text{m}$



$D_c = 0$  @ 1,06µm



core diameter = 1,5µm  $\Lambda = 2\mu\text{m}$



$D_c = 0$  @ 0,56µm

End of chapter 4



With the support of the  
Erasmus+ Programme  
of the European Union

