
# **CHAPTER 4**

# Dispersion in optical fibers

Dominique PAGNOUX










#### **DEFINITION AND CAUSES OF DISPERSION IN OPTICAL FIBERS**

DISPERSION: linear phenomenon resulting in a change (generally an increase) of the duration of a pulse when propagating in a fiber



#### 3 causes of dispersion:

- intermodal dispersion (in multimode regime) → D<sub>I</sub>
- chromatic dispersion → D<sub>c</sub>
- polarization mode dispersion → PMD
- \* In the multimode regime: D<sub>1</sub> >> D<sub>c</sub> of each mode >> PMD of each mode
  - → D<sub>c</sub> and PMD are neglected
- \* In the single mode régime :  $D_1 = 0$
- if D<sub>c</sub> of the fundamental mode >> PMD (usual case) → D<sub>c</sub> only is taken into account and PMD is neglected
- si D<sub>c</sub> of the fundamental mode ~0 → PMD must be taken onto account (for very high bit rate transmissions)










#### INTERMODALE DISPERSION




- → due to the fact that the each excited mode has its own group velocity, different from that of the others
- → D<sub>I</sub> = pulse broadening per unit of length along which light propagates (ns/km)







#### INTERMODALE DISPERSION



- → due to the fact that the each excited mode has its own group velocity, different from that of the others
- $\rightarrow$  D<sub>I</sub> = pulse broadening per unit of length along which light propagates (ns/km)

group delay: 
$$t_g = \frac{L}{v_g}$$

For a step index fiber 
$$\rightarrow$$
  $v_g \approx \frac{c}{n_1} \sin i$ 

$$\underline{\text{ray 1}} \rightarrow \sin i = l \rightarrow \qquad v_g \approx \frac{c}{n_1} \quad \Rightarrow \qquad t_{g1} \approx \frac{L}{c} n_1$$


$$\underline{\text{ray 2}} \rightarrow \qquad \sin i_{\min} = \frac{n_2}{n_1} \quad \Rightarrow \qquad v_g \approx \frac{c}{n_1} \frac{n_2}{n_1} \rightarrow$$

$$\frac{\operatorname{ray} 1 \to \sin i = 1}{\operatorname{ray} 2 \to \sin i} = \frac{r_{2}}{n_{1}} \xrightarrow{} v_{g} \approx \frac{c}{n_{1}} \xrightarrow{} t_{g_{1}} \approx \frac{L}{c} n_{1}$$

$$\frac{\operatorname{ray} 2 \to \sin i}{\operatorname{ray} 2 \to \sin i} = \frac{n_{2}}{n_{1}} \xrightarrow{} v_{g} \approx \frac{c}{n_{1}} \frac{n_{2}}{n_{1}} \xrightarrow{} t_{g_{2}} \approx \frac{L}{c} \frac{n_{1}^{2}}{n_{2}}$$

$$t_{g_{2}} \approx \frac{L}{c} \frac{n_{1}^{2}}{n_{2}} \xrightarrow{} \approx \frac{L}{c} n_{1} \cdot \left(\frac{n_{1}}{n_{2}} - 1\right) \approx \frac{L}{c} n_{1} \left(\frac{n_{1} - n_{2}}{n_{2}}\right)$$

With 
$$\Delta = \left(\frac{n_1^2 - n_2^2}{2n_1^2}\right) = \frac{(n_1 + n_2)(n_1 - n_2)}{2n_1^2} \approx \frac{2n_1(n_1 - n_2)}{2n_1^2} \approx \frac{n_1 - n_2}{n_1}$$
  $\longrightarrow$   $\tau = \frac{L}{C} n_1 \Delta$  (step index fiber)











## **INTERMODALE DISPERSION (step index fiber)**

Definition

$$D_I \triangleq \frac{\tau}{L} = \frac{n_1 \cdot \Delta}{c}$$
 (en ns/km)

reminder: 
$$\tau = \frac{L}{c} n_1 \Delta$$

Modulation bandwidth, for a fiber of length L:  $B=1/\tau$  (generally expressed in MHz)

B.L = 
$$B_L = L/\tau = 1/D_I = constant$$
 (generally expressed in MHz.km)







## **INTERMODALE DISPERSION (step index fiber)**

Définition

$$D_I \triangleq \frac{\tau}{L} = \frac{n_1 \cdot \Delta}{c}$$
 (en ns/km)

 $\left(\text{reminder}: \tau = \frac{L}{c} n_1 \Delta\right)$ 

Modulation bandwidth, for a fiber of length L:  $B=1/\tau$  (generally expressed in MHz)

B.L =  $B_1 = L/\tau = 1/D_1 = constant$  (generally expressed in MHz.km)

#### Example:

Step index fiber, length L= 3km with n1 = 1,465 and n2 =1,45

$$\tau = 3 \cdot \frac{1}{3 \cdot 10^5} \cdot 1,465 \cdot \left(\frac{1,465-1,45}{1,45}\right) = 1,52 \cdot 10^{-7} s = 152 \text{ ns}$$

$$B = \frac{1}{\tau} = \frac{1}{152 \cdot 10^{-9}} = 6,58 \cdot 10^{6} \text{Hz} = 6,58 \text{ MHz}$$

$$B_L = \frac{1}{D_c} = \frac{1}{51 \cdot 10^{-9}} \approx 20 \cdot 10^6 \text{Hz.km} \approx 20 \text{ MHz.km}$$

Optimized graded index fiber


$$\tau' = \tau/100$$

$$B_{L}' = 100.B_{L}$$









 $\Delta\lambda = \lambda^2$ .  $\Delta f/c$  where  $\Delta f$  = spectral bandwidth of the pulse with  $\Delta t$ .  $\Delta f$  = cte

if 
$$\Delta t$$
=10ps with  $\lambda_0$  = 1 $\mu$ m

$$\Delta \lambda = \frac{\left(10^{-6}\right)^2}{3.10^8} \times \frac{1}{10.10^{-12}} = 3.10^{-10} m = 0,3nm \qquad \text{(with } \Delta t.\Delta f=1\text{)}$$

#### causes of chromatic dispersion:

- dispersive material  $\rightarrow$  n=f( $\lambda$ )  $\rightarrow$  v<sub> $\phi$ </sub>=c/n=f( $\lambda$ )  $\rightarrow$  v<sub>g</sub>=f( $\lambda$ )  $\rightarrow$  material dispersion (D<sub>mat</sub>)
- when the wave is guided,  $\beta = f(V) = f(\omega) \rightarrow v_g = d\omega/d\beta = f(\lambda) \rightarrow guide dispersion (D_{gui})$


In first approximation :  $D_c \approx D_{mat} + D_{qui}$ 











<u>Definition</u>:

$$D_c = \frac{ au}{L.\Delta\lambda}$$


expressed in ps/(nm.km)


 $\Delta t + \tau$ 













<u>Definition</u>:

$$D_c = \frac{\tau}{L.\Delta\lambda}$$

expressed in ps/(nm.km)



$$\tau = \left| t_g(\lambda_2) - t_g(\lambda_1) \right| \simeq \frac{dt_g}{d\lambda} \Delta \lambda$$



 $D_c = \frac{1}{L} \frac{dt_g}{d\lambda}$ 










$$D_c = \frac{1}{L} \frac{dt_g}{d\lambda}$$

$$D_{c} = \frac{t_{gR} - t_{gB}}{L (\lambda_{R} - \lambda_{B})}$$
 en ps/(nm.km)



$$v_{gR} > v_{gB} \Rightarrow t_{gR} < t_{gB}$$

 $\begin{aligned} &D_{c}<0\\ &\text{Normal dispersion} \end{aligned}$ 

$$v_{gB} > v_{gR} \Longrightarrow t_{gB} < t_{gR}$$

$$\label{eq:Dc} D_c > 0$$
 Anomalous dispersion









#### **CHROMATIC DISPERSION: remarks**

$$D_{c} = \frac{1}{L} \frac{dt_{g}}{d\lambda} = \frac{1}{L} \frac{d}{d\lambda} \left( \frac{L}{v_{g}} \right) = \frac{d}{d\lambda} \left( \frac{d\beta}{d\omega} \right) = \frac{d}{d\omega} \left( \frac{d\beta}{d\omega} \right) \cdot \frac{d\omega}{d\lambda} = -\frac{2\pi c}{\lambda^{2}} \frac{d^{2}\beta}{d\omega^{2}}$$

 $\Rightarrow$  the dispersion curve  $\beta$ =f(ω) allows to calculate the chromatic dispersion (taking into account the actual values  $n_1(\lambda)$  and  $n_2(\lambda)$  at each wavelength)







#### **CHROMATIC DISPERSION: remarks**

$$D_{c} = \frac{1}{L} \frac{dt_{g}}{d\lambda} = \frac{1}{L} \frac{d}{d\lambda} \left( \frac{L}{v_{g}} \right) = \frac{d}{d\lambda} \left( \frac{d\beta}{d\omega} \right) = \frac{d}{d\omega} \left( \frac{d\beta}{d\omega} \right) \cdot \frac{d\omega}{d\lambda} = -\frac{2\pi c}{\lambda^{2}} \frac{d^{2}\beta}{d\omega^{2}}$$

 $\rightarrow$  the dispersion curve  $\beta$ =f( $\omega$ ) allows calculating the chromatic dispersion (taking into account the actual values  $n_1(\lambda)$  and  $n_2(\lambda)$  at each wavelength)

Taylor expansion of the spectral phase of the guided wave:

$$\varphi(\omega) = \beta L = \beta(\omega_0) \cdot L + L \cdot \frac{d\beta}{d\omega} (\omega - \omega_0) + \frac{L}{2} \frac{d^2\beta}{d\omega^2} (\omega - \omega_0)^2 + \dots$$

out of the "guided optics" community,

$$\frac{d^2\beta}{d\alpha^2}$$
 is often called "group velocity dispersion"

→ inappropriate denomination and risk of confusion with D<sub>c</sub>

In fact 
$$\frac{d^2\beta}{d\omega^2}$$

in fact  $\frac{d^2\beta}{d^2}$  is proportional to the dispersion of group delay









#### **CALCULATION OF THE MATERIAL DISPERSION**

- → plane wave (= propagating wave NOT GUIDED)
- $\rightarrow$  dispersive propagation medium :  $n_1 = f(\lambda)$

$$t_{g} = t_{mat} = \frac{L}{v_{g}} = \frac{L}{c} N_{g} = \frac{L}{c} \left( n_{1} - \lambda \frac{dn_{1}}{d\lambda} \right)$$







#### **CALCULATION OF THE MATERIAL DISPERSION**

- → plane wave (= propagating wave NOT GUIDED)
- $\rightarrow$  dispersive propagation medium :  $n_1 = f(\lambda)$

$$t_{g} = t_{mat} = \frac{L}{v_{g}} = \frac{L}{c} N_{g} = \frac{L}{c} \left( n_{1} - \lambda \frac{dn_{1}}{d\lambda} \right)$$

$$\tau_{mat} = \Delta t_{g} = \frac{dt_{mat}}{d\lambda} \Delta \lambda = \frac{L\Delta\lambda}{c} \frac{d}{d\lambda} \left( n_{1} - \lambda \frac{dn_{1}}{d\lambda} \right)$$

$$= \frac{L}{c} \Delta \lambda \cdot \left( \frac{dn_{1}}{d\lambda} - \left( 1x \frac{dn_{1}}{d\lambda} + \lambda \frac{d^{2}n_{1}}{d\lambda^{2}} \right) \right)$$

$$= -\frac{\lambda L}{c} \Delta \lambda \cdot \frac{d^{2}n_{1}}{d\lambda^{2}}$$







#### **CALCULATION OF THE MATERIAL DISPERSION**

- → plane wave (= propagating wave NOT GUIDED)
- $\rightarrow$  dispersive propagation medium :  $n_1 = f(\lambda)$

$$t_{g} = t_{mat} = \frac{L}{v_{g}} = \frac{L}{c} N_{g} = \frac{L}{c} \left( n_{1} - \lambda \frac{dn_{1}}{d\lambda} \right)$$

$$\tau_{mat} = \Delta t_{g} = \frac{dt_{mat}}{d\lambda} \Delta \lambda = \frac{L\Delta\lambda}{c} \frac{d}{d\lambda} \left( n_{1} - \lambda \frac{dn_{1}}{d\lambda} \right)$$

$$= \frac{L}{c} \Delta \lambda \cdot \left( \frac{dn_{1}}{d\lambda} - \left( 1x \frac{dn_{1}}{d\lambda} + \lambda \frac{d^{2}n_{1}}{d\lambda^{2}} \right) \right)$$

$$= -\frac{\lambda L}{c} \Delta \lambda \cdot \frac{d^{2}n_{1}}{d\lambda^{2}}$$


$$D_{mat} = \frac{\tau_{mat}}{L.\Delta\lambda} = -\frac{\lambda}{c} \frac{d^2 n_1}{d\lambda^2}$$







$$D_{mat} = -\frac{\lambda}{c} \frac{d^2 n_1}{d\lambda^2}$$



For pure silica:

$$B_1 = 0.696166300$$
  
 $B_2 = 0.407942600$ 

$$B_3 = 0.897479400$$

$$C_1 = 4.67914826 \times 10^{-3} \, \mu \text{m}$$

$$\begin{array}{c} B_3^2 = 0.897479400 \\ C_1 = 4.67914826x10^{-3} \ \mu\text{m}^2 \\ C_2 = 1.35120631x10^{-2} \ \mu\text{m}^2 \\ C_3 = 97.9340025 \ \mu\text{m}^2 \end{array}$$


 $n(SiO_2) = f(\lambda)$ 












$$D_{mat} = -\frac{\lambda}{c} \frac{d^2 n_1}{d\lambda^2}$$















$$D_{mat} = -\frac{\lambda}{c} \frac{d^2 n_1}{d\lambda^2}$$




























example let us consider a beam from a laser diode emitting at 850nm, with  $\Delta\lambda$  = 40nm, launched in a fiber with a length L= 2km



 $D_{mat} = -75ps/(nm.km)$ 



$$\tau_{mat} = L.\Delta \lambda. |D_{mat}|$$
$$= 2x40x75 = 6000 ps = 6ns$$









- → guided wave
- $\Rightarrow$  non dispersive propagation medium  $\Rightarrow \frac{dn_1}{d\lambda} = 0$ ;  $\frac{dn_2}{d\lambda} = 0$ ;  $\frac{d\Delta}{d\lambda} = 0$

$$v_g = \frac{d\omega}{d\beta}$$
 et  $t_g = \frac{L}{v_g} = L\frac{d\beta}{d\omega} = \frac{L}{c}\frac{d\beta}{dk_0}$  (car  $\omega = k_0.c$ )

Goal: express t<sub>a</sub> as a function of B and V (→ allowing to exploit the dispersion curves B=f(V))

One easily shows that:

$$\beta = k_0 \left[ n_2 + n_1 \Delta B \right]$$

$$k_0 = \frac{V}{a \cdot n_1 \sqrt{2\Delta}}$$

$$t_{g} = t_{gui} = \frac{L}{c} \left[ n_{2} + n_{1} \Delta \frac{d(VB)}{dV} \right]$$


see the development of the calculations in pdf pages 10 et 11







$$t_{gui} = \frac{L}{c} \left[ n_2 + n_1 \Delta \frac{d(VB)}{dV} \right]$$









$$t_{gui} = \frac{L}{c} \left[ n_2 + n_1 \Delta \frac{d(VB)}{dV} \right]$$

temporal broadening:

$$\tau_{gui} = \Delta t_{gui} = \frac{dt_{gui}}{d\lambda} \Delta \lambda$$

(see slide number 9)


Dispersion due to guiding effect :  $D_{ extit{gui}} = rac{ au_{ extit{gui}}}{L.\Delta\lambda}$ 



resulting in:

$$D_{gui} = -\frac{n_1 \Delta}{c \lambda} V \frac{d^2 (VB)}{dV^2}$$


(see the development of the calculations in pdf page 12)











$$D_{gui} = -\frac{n_1 \Delta}{c \lambda} V \frac{d^2 (VB)}{dV^2}$$

Example: case of a fiber with

$$a = 4.5 \mu m$$
 ON = 0,105  $n1 = 1,46$ 

à 
$$\lambda = 1,55 \mu m$$

$$\rightarrow \Delta = \frac{ON^2}{2n_1^2} = 2,83.10^{-3}$$

$$\rightarrow V = \frac{2\pi}{\lambda}aON = 1,91$$

$$\rightarrow V \frac{d^2(VB)}{dV^2} \simeq 0.6$$

$$D_{gui} = -\frac{1,46 \times 2,83.10^{-3}}{3.10^{8} \times 1.55.10^{-6}} \times 0,6 = -510^{-6} \text{s/(m.m)} = -5 \text{ps/(nm.km)}$$










#### **CURVES OF THE CHROMATIC DISPERSION versus WAVELENGTH**

Example with a step index fiber:  $n_1 = 1.46$   $n_2 = 1.455$   $a = 4 \mu m$ 

$$n_2 = 1.455$$

$$a = 4 \mu m$$











#### **CURVES OF THE CHROMATIC DISPERSION versus WAVELENGTH**

Example with a step index fiber:  $n_1 = 1.46$   $n_2 = 1.455$   $a = 4 \mu m$ 

$$n_2 = 1.455$$

$$a = 4 \mu m$$













#### **CURVES OF THE CHROMATIC DISPERSION versus WAVELENGTH**

Example with a step index fiber:  $n_1 = 1.46$   $n_2 = 1.455$   $a = 4 \mu m$ 

$$n_2 = 1.455$$
  $a = 4$ 













#### CURVES OF THE CHROMATIC DISPERSION VERSUS WAVELENGTH



## How can we change the chromatic dispersion of an optical fiber ?

- $\rightarrow$  By changing the material dispersion ????  $\rightarrow$  no
- → By changing the dispersion of the guide !!!
  - **⇒** Working with higher order modes
  - **⇒** Working in the single mod regime, but with a fiber having a modified index profile
    - multiclad fibers ("DS fibers", "DF fibers...)
    - Air silica microstructured optical fibers (MOFs so called "PCFs")
    - Bragg fibers or photonic bandgap fibers











#### **HOW CAN WE CHANGE THE DISPERSION OF THE GUIDE?**


$$D_{g} = -\frac{1}{\pi^{2} n_{2} c} \frac{\lambda}{w_{0}^{2}} \left( \frac{\lambda}{w_{0}} \frac{dw_{0}}{d\lambda} - \frac{1}{2} \right)$$

Pierre Sansonetti, Elect. Letters, vol 18, n°15, pp 647-648 (1982)

$$\lambda_1 < \lambda_2 < \lambda_3$$

















## **DISPERSION SHIFTED FIBERS: MULTICLAD FIBERS**










$$\mathbf{D} = -\frac{\lambda}{c} \frac{d^2 n_e}{d\lambda^2}$$









#### **DISPERSION SHIFTED FIBERS: A LARGE VARIETY OF INDEX PROFILES**








Continuols dad profile








## DISPERSION SHIFTED OR FLATTENED FIBERS














#### **DISPERSION SHIFTED OR FLATTENED FIBERS**















## OTHER KINDS OF FIBERS FOR THE MANAGEMENT OF THE DISPERSION (1)


\* fibers with Dg << 0 (compensating fibers)






JL Auguste et al. Optical fiber technology Vol. 24, issue 1, pp. 442- (2006)

#### index profile



Distribution of the field versus wavelength



measured chromatic dispersion











## OTHER KINDS OF FIBERS FOR THE MANAGEMENT OF THE DISPERSION (2)


\* fibers with Dg > 0 at short wavelengths

→ Bragg Fibers



→ Hollow core photonic crystal fibers













## OTHER KINDS OF FIBERS FOR THE MANAGEMENT OF THE DISPERSION (3)

\* fibers with Dg specially managed for particular applications

→ Air silica microstructured optical fibers :



diameter of holes :d pitch :  $\Lambda$ 






flattened dispersion 1100 nm – 1600 nm



d= 1,9
$$\mu$$
m  $\Lambda$ =2,3 $\mu$ m

Dc = 0 @ 1,06 $\mu$ m



core diameter = 1,5
$$\mu$$
m  $\Lambda$ =2 $\mu$ m Dc = 0 @ 0,56 $\mu$ m









#### End of chapter 4





