

Pulse dispersion in optical fibers

D. Pagnoux

Whatever its origin, the **dispersion** is a linear phenomenon which results in a temporal broadening of a pulse during its propagation in a medium (with or without guiding).




Figure 1 : schematic representation of usual effect of dispersion on the temporal shape of a pulse

In an optical fiber, dispersion may have three different causes :

- Group velocity of modes, around a given central wavelength, are different → **Intermodal dispersion** D_I (or simply “modal dispersion”), only in multimode fibers ;
- In a given mode, group velocities of wave packets centered around different wavelengths are different → **chromatic dispersion** D_C of the mode ;
- In a given mode, at a given wavelength, group velocities of the two orthogonal eigen polarizations are different → **polarization mode dispersion** (PMD)

In a multimode fiber, D_I , D_C and PMD can exist at the same time but, as $\text{PMD} \ll D_C \ll D_I$, we can neglect D_C and PMD → D_I only is taken into account.

In a single mode fiber, $D_I=0$. Most of the time (for example in a standard fibre @ $1.55\mu\text{m}$) we have $\text{PMD} \ll D_C$ and thus we can neglect PMD → only D_C is taken under consideration.

In a single mode fiber with an index profile specially designed for obtaining $D_C \sim 0$ → PMD must be taken into account (case of high bit rate telecom fibers).

I. Intermodale dispersion (in multimode fibers)

The energy of a pulse launched into a multimode fiber is split in all the transverse modes of this fiber (decomposition basis). The excitation coefficient of each mode is the normalized integral overlap between the spatial distribution of the incident beam and that of the mode. Each mode having its own group velocity, the energy will exit the fiber over time, according to the excited modes.

I.1 Approximate calculation of the temporal broadening τ of a pulse, in a step index fiber

We consider the simplified approach based on ray tracing (valid only if the core diameter is large compared to the wavelength \rightarrow multimode fiber).




Figure 2 : schematic representation of the fastest ray and of the slowest ray in the core of a step index fiber.

Group propagation time (time of flight of a ray) : $t_g = \frac{L}{v_g}$ avec $v_g \approx \frac{c}{n_1} \sin i$

For the ray 1 $\rightarrow \sin i = 1 \rightarrow v_g \approx \frac{c}{n_1} \rightarrow t_{g1} = \frac{L}{c} n_1$

For the ray 2 $\rightarrow \sin i_{\min} = \frac{n_2}{n_1} \rightarrow v_g \approx \frac{c}{n_1} \frac{n_2}{n_1} \rightarrow t_{g2} = \frac{L}{c} \frac{n_1^2}{n_2}$

Maximal group delay (= maximal temporal broadening of the pulse, due to propagation in the multimode regime) : $\Delta t_g = \tau = t_{g2} - t_{g1} = \frac{L}{c} n_1 \left(\frac{n_1}{n_2} - 1 \right) = \frac{L}{c} n_1 \left(\frac{n_1 - n_2}{n_2} \right)$

With n_2 close to n_1 we have $\Delta = \left(\frac{n_1^2 - n_2^2}{2n_1^2} \right) = \frac{(n_1 + n_2)(n_1 - n_2)}{2n_1^2} \approx \frac{2n_1(n_1 - n_2)}{2n_1^2} \approx \frac{n_1 - n_2}{n_1}$

thus $\tau = \frac{L}{c} n_1 \Delta$

By definition, the intermodal dispersion is : $D_I = \frac{\tau}{L} \approx \frac{n_1 \Delta}{c}$ (unit : ns/km)

The modulation bandwidth B after a propagation length L , is approximately given by $B=1/\tau$ (unit : MHz).

Thus, per unit of length : $B_L = 1/D_I$ (MHz.km)

I.2 Example

Let us consider a step index fiber, of length $L= 3\text{km}$ with $n_1 = 1.465$ and $n_2 = 1.45$ working around the operating wavelength λ_T .

$$\tau = 3 \times \frac{1}{3 \times 10^5} \times 1.465 \times \left(\frac{1.465-1.45}{1.45} \right) = 1.52 \times 10^{-7} \text{ s} = 152 \text{ ns}$$

$$D_I = \frac{152}{3} \approx 51 \text{ ns/km}$$

$$\text{Bandwidth for this section of fiber : } B = \frac{1}{\tau} = \frac{1}{152 \times 10^{-9}} = 6.58 \times 10^6 \text{ Hz} = 6.58 \text{ MHz}$$

$$\text{The modulation bandwidth per unit of length is : } B_L = \frac{1}{D_I} = \frac{1}{51 \times 10^{-9}} \approx 20 \times 10^6 \text{ Hz.km} \approx 20 \text{ MHz.km}$$

In a graded index fiber, it is possible to equalize the propagation times of certain rays (helical rays, meridian rays...) by adjusting the index profile, but it is not possible to equalize the propagation times of all the existing rays.

With an optimized profile (Gloge profile, very close to a parabolic index) we can reduce τ by a factor $1/\Delta \sim 1/10^{-2} \sim 100$.

II. Chromatic dispersion

II.1 Definitions

By definition, a pulse has a limited duration Δt (modulation by a pulse of a carrier wave centered at f_0 (or λ_0)). The width of its spectrum is Δf such that $\Delta t \cdot \Delta f = \kappa$ ($\kappa \approx 1$, depending on the temporal shape of the pulse).




Figure 3 : temporal shape and spectrum of a light pulse

$$\text{With } f = \frac{c}{\lambda} \quad df = -c \frac{d\lambda}{\lambda^2} \Rightarrow \Delta\lambda = \frac{\lambda^2}{c} \Delta f \approx \frac{\lambda^2}{c} \frac{1}{\Delta t}$$

Example : if $\Delta t = 10\text{ps}$ and $\lambda_0 = 1\mu\text{m}$

$$\Delta\lambda = \frac{(10^{-6})^2}{3 \cdot 10^8} \times \frac{1}{10 \cdot 10^{-12}} = 3 \cdot 10^{-10} \text{m} = 0.3 \text{nm}$$


The chromatic dispersion is due to two main causes :

$$\left. \begin{array}{l} * \text{ the refractive index of the material depends on } \lambda \\ \rightarrow n = f(\lambda) : \text{ the material is dispersive} \\ \lambda \text{ varies} \Rightarrow n(\lambda) \text{ varies} \Rightarrow v_\phi = \frac{c}{n(\lambda)} \text{ varies} \\ \Rightarrow N_g = n(\lambda) - \lambda \frac{dn(\lambda)}{d\lambda} \text{ varies} \\ \Rightarrow v_g = \frac{c}{N_g} \text{ varies with } \lambda \end{array} \right\} \text{material dispersion (D}_{\text{mat}})$$

$$\left. \begin{array}{l} * \text{ when the wave is guided, even if the material is not dispersive} \\ \beta = f(\lambda) \text{ varies} \Rightarrow v_g = \frac{d\omega}{d\beta} \text{ varies with } \lambda \end{array} \right\} \text{dispersion of the guide (D}_{\text{gui}})$$

In a first approximation, the chromatic dispersion is $D_c \approx D_{\text{mat}} + D_{\text{gui}}$.

By definition $D_c = \frac{\tau}{L \Delta \lambda}$ unit : ps/(nm.km) (1) where τ is the temporal broadening of the pulse, L is the length of the fiber and $\Delta \lambda$ is the spectral width of the pulse.



$$\tau = |t_g(\lambda_2) - t_g(\lambda_1)| \approx \frac{dt_g}{d\lambda} \Delta \lambda \quad (2)$$

with t_g the group propagation time : $t_g = \frac{L}{v_g}$

Thus $D_c = \frac{1}{L} \frac{dt_g}{d\lambda}$ (s/m.m in the SI) (3)

In practical applications, D_c is generally expressed in ps/(nm.km)

Figure 4 : definition of the chromatic dispersion around λ_0

Comments :

➤ From relation (3), we can write:

$$D_c = \frac{1}{L} \frac{dt_g}{d\lambda} = \frac{1}{L} \frac{d}{d\lambda} \left(\frac{L}{v_g} \right) = \frac{d}{d\lambda} \left(\frac{d\beta}{d\omega} \right) = \frac{d}{d\omega} \left(\frac{d\beta}{d\omega} \right) \cdot \frac{d\omega}{d\lambda} = -\frac{2\pi c}{\lambda^2} \frac{d^2\beta}{d\omega^2} \quad (4)$$

As pointed out in the chapter 2, the expression confirms that the chromatic dispersion of a mode can be deduced from the dispersion curve of this mode presented under the form $\beta=f(\omega)$ or, more difficult, from the dispersion curve presented under the form $\omega=f(\beta)$.

➤ Warning : out of the guided optics community, people are used to consider the limited development of the phase term around the central pulsation ω_0 :

$$\varphi(\omega) = \beta L = \beta(\omega_0) \cdot L + L \cdot \frac{d\beta}{d\omega} (\omega - \omega_0) + \frac{L}{2} \frac{d^2\beta}{d\omega^2} (\omega - \omega_0)^2 + \dots$$

where $L \frac{d\beta}{d\omega} = \frac{L}{v_g} = t_g$ represents the propagation time of a pulse having its spectrum centered at ω_0 , over the length L , and $\frac{d^2\beta}{d\omega^2}$ is improperly called "group velocity dispersion" (the factor $L \frac{d^2\beta}{d\omega^2}$ more precisely represents a dispersion of the group propagation time). Thus, we should not confuse this "group velocity dispersion" with the chromatic dispersion defined in (3) and (4). In particular, their signs are opposite: a positive group velocity dispersion (so-called "normal dispersion" occurring at short wavelengths (see below)) corresponds to a negative chromatic dispersion.

II.2 Expressions of the group propagation time t_g and of the temporal broadening τ .

Let us first remind the following relations: $v_g = \frac{d\omega}{d\beta}$ et $t_g = \frac{L}{v_g} = L \frac{d\beta}{d\omega} = \frac{L}{c} \frac{d\beta}{dk_0}$ (since $\omega = k_0 c$) (5)

$$t_g = \frac{L}{v_g} = \text{ and } v_g = \frac{c}{N_g} \Rightarrow t_g = \frac{L}{c N_g} = \frac{L}{c} \left(n_e - \lambda \frac{dn_e}{d\lambda} \right)$$

Expression of t_g as a function of λ :

- If light propagates in free space, in a medium of index $n \rightarrow n_e = n$

$$\text{thus } t_g = \frac{L}{c} \left(n - \lambda \frac{dn}{d\lambda} \right)$$

- If propagating light is guided \rightarrow we must use $t_g = \frac{L}{c} \frac{d\beta}{dk_0}$ with

$$\bullet \quad \frac{k_0}{dk_0} = -\frac{\lambda}{d\lambda} \Rightarrow dk_0 = -k_0 \frac{d\lambda}{\lambda} = -\frac{2\pi d\lambda}{\lambda^2} \quad \text{thus} \quad t_g = -\frac{L}{c} \frac{\lambda^2}{2\pi} \frac{d\beta}{d\lambda} \quad (6)$$

The temporal broadening of a pulse having a spectral width equal to $\Delta\lambda$ is given by (2) : $\tau \approx \frac{dt_g}{d\lambda} \Delta\lambda$.

$$\text{Using (6), we can deduce : } \tau = -\frac{L \Delta\lambda}{2\pi c} \cdot \frac{d}{d\lambda} \left(\lambda^2 \frac{d\beta}{d\lambda} \right) = -\frac{L \Delta\lambda}{2\pi c} \cdot \left(2\lambda \frac{d\beta}{d\lambda} + \lambda^2 \frac{d^2\beta}{d\lambda^2} \right) \quad (7)$$

Using the data extracted from the normalized dispersion curve of a mode $B = f(V)$ and by denormalizing, we can plot the curve $\beta = f(\lambda)$, then calculate the first and second derivatives, respectively $\frac{d\beta}{d\lambda}$ and $\frac{d^2\beta}{d\lambda^2}$. Finally, from (7), we can find $D_c = -\frac{1}{2\pi \cdot c} \cdot \left(2\lambda \frac{d\beta}{d\lambda} + \lambda^2 \frac{d^2\beta}{d\lambda^2} \right)$.

Comment : this expression takes into account both the dispersion of the guide AND the material dispersion. The material dispersion is taken in consideration when B is denormalized at each wavelength, because the indices of the core and of the cladding (respectively n_1 and n_2) which occur in the relation between B and β are in fact two functions of the wavelength ($n_1(\lambda)$ and $n_2(\lambda)$) given by the Sellmeier relations.

II.3 Study of the dispersions considered separately

II.3.1 Material dispersion

Hypotheses : 1. Plane wave \rightarrow propagation of non guided light (i.e. no guided wave)
 2. the index of the medium (the core) depends on $\lambda \rightarrow n_1(\lambda) \rightarrow$ dispersive medium
 3. we consider the temporal broadening of a pulse having a spectral width equal to $\Delta\lambda$

$$t_g = t_{mat} = \frac{L}{v_g} = \frac{L}{c} N_g = \frac{L}{c} \left(n_1 - \lambda \frac{dn_1}{d\lambda} \right)$$

$$\begin{aligned} \tau_{mat} = \Delta t_g &= \frac{dt_{mat}}{d\lambda} \Delta\lambda = \frac{L\Delta\lambda}{c} \frac{d}{d\lambda} \left(n_1 - \lambda \frac{dn_1}{d\lambda} \right) \\ &= \frac{L}{c} \Delta\lambda \cdot \left(\frac{dn_1}{d\lambda} - \left(1x \frac{dn_1}{d\lambda} + \lambda \frac{d^2n_1}{d\lambda^2} \right) \right) \\ &= -\frac{\lambda L}{c} \Delta\lambda \cdot \frac{d^2n_1}{d\lambda^2} \quad (\lambda \text{ being the wavelength in the vacuum}) \end{aligned}$$

$D_c \text{ dispersion due to the material} = D_{mat} = \frac{\tau_{mat}}{L \cdot \Delta\lambda} = -\frac{\lambda}{c} \frac{d^2n_1}{d\lambda^2} \quad (8)$




Figure 5: Curves $n=f(\lambda)$ and $dn/d\lambda=f(\lambda)$ in pure silica




Figure 6: Curve $d^2n/d\lambda^2=f(\lambda)$ in pure silica




Figure 7: Material dispersion in pure silica, versus wavelength

Exemple : Let us consider a single mode fiber of length $L=1\text{km}$, in which light from a LED with $\Delta\lambda=40\text{nm}$ around $\lambda_0=850\text{nm}$ is launched.

$$D_{\text{mat}} = -75\text{ps}/(\text{nm.km}). \quad \tau_{\text{mat}} = L \cdot \Delta\lambda \cdot |D_{\text{mat}}| = 1 \times 40 \times 75 = 3000\text{ps} = 3\text{ns}$$

This temporal broadening is due to material dispersion, regardless of the guiding phenomenon.

II.3. 2 Dispersion of the guide

Hypothesis : non dispersive medium $\Rightarrow \frac{dn_1}{d\lambda} = 0 ; \frac{dn_2}{d\lambda} = 0 ; \frac{d\Delta}{d\lambda} = 0$

$$\text{since } k_0 = \frac{2\pi}{\lambda} \Rightarrow \frac{dn_1}{dk_0} = \frac{dn_2}{dk_0} = \frac{d\Delta}{d\lambda} = 0$$

From (5), the group propagation time is $t_g = t_{gui} = \frac{L}{c} \frac{d\beta}{dk_0}$

Our goal is to express t_{gui} as a function of B and V in order to be able to find t_{gui} from the normalized dispersion curve $B=f(V)$

We first express β as a function of B . (Later, we'll express k_0 as a function of V).

Starting from $B = \frac{\beta^2 - k_0^2 n_2^2}{k_0^2 (n_1^2 - n_2^2)}$ (see chapter 3) with $\beta = k_0 n_e$

$$\rightarrow B = \frac{n_e^2 - n_2^2}{n_1^2 - n_2^2} = \frac{(n_e - n_2) \cdot (n_e + n_2)}{(n_1 - n_2) \cdot (n_1 + n_2)} \quad n_2 \leq n_e \leq n_1$$

In the weakly guidance approximation, n_1 is close to n_2 and thus $n_1 + n_2 \approx 2n_1$ et $n_1 + n_e \approx 2n_1$

$$B \approx \frac{n_e - n_2}{n_1 - n_2} = \frac{\beta / k_0 - n_2}{n_1 - n_2} \Leftrightarrow \beta \approx [B(n_1 - n_2) + n_2] \cdot k_0$$

If we make use of $\Delta = \frac{n_1^2 - n_2^2}{2n_1^2} = \frac{(n_1 + n_2)(n_1 - n_2)}{2n_1^2} \approx \frac{2n_1(n_1 - n_2)}{2n_1^2} \approx \frac{n_1 - n_2}{n_1}$ (see chap. 3)

thus $n_1 - n_2 \approx n_1 \Delta$ and β becomes: $\beta = k_0 [n_2 + n_1 \Delta B]$ (9)

By reporting (9) in (5) we obtain: $t_{gui} = \frac{L}{c} \frac{d}{dk_0} [k_0 n_2 + n_1 \Delta k_0 B]$

$$= \frac{L}{c} \left[n_2 + n_1 \Delta \frac{d(k_0 B)}{dk_0} \right] \quad (10)$$

Now, we can introduce $V = k_0 a \sqrt{n_1^2 - n_2^2} = k_0 \cdot \underbrace{a \cdot n_1 \sqrt{2\Delta}}_A \Rightarrow k_0 = \frac{V}{A}$ (with $A = \text{constant}$)

$$\text{In (10) : } \frac{d(k_0 B)}{dk_0} = \frac{d\left(\frac{V}{A} B\right)}{d\left(\frac{V}{A}\right)} = \frac{d(VB)}{dV}$$

$$\text{and (10) becomes: } t_{\text{gui}} = \frac{L}{c} \left[n_2 + n_1 \Delta \frac{d(VB)}{dV} \right] \quad (11)$$




Figure 8 : Curves of $d(VB)/dV$ versus V for different LP modes

Note : on the dispersion curve, we can see that, for large values of V , B tends toward 1 (almost constant), thus $VB \rightarrow V$, et $\frac{d(VB)}{dV} \rightarrow 1$, which can be seen on the curve $\frac{d(VB)}{dV} = f(V)$

For a given mode, what is the value of the pulse broadening τ_{gui} due to the dispersion of the guide ?

$$\begin{aligned}\tau_{\text{gui}} &= \Delta t_g = \frac{dt_{\text{gui}}}{d\lambda} \Delta\lambda \\ \tau_{\text{gui}} &= \frac{d}{d\lambda} \left[\frac{L}{c} \left(n_2 + n_1 \Delta \frac{d(VB)}{dV} \right) \right] \Delta\lambda = \frac{L}{c} n_1 \Delta \frac{d}{d\lambda} \left(\frac{d(VB)}{dV} \right) \Delta\lambda \\ &= \frac{L}{c} n_1 \Delta \frac{d}{dV} \left(\frac{d(VB)}{dV} \right) \cdot \frac{dV}{d\lambda} \Delta\lambda\end{aligned}\quad (12)$$

however $\frac{dV}{d\lambda} = -\frac{2\pi}{\lambda^2} a \text{ ON} = -\frac{V}{\lambda}$ thus : $\tau_{\text{gui}} = -\frac{L}{c} n_1 \Delta \frac{V}{\lambda} \frac{d^2(VB)}{dV^2} \Delta\lambda$

$D_c \text{ dispersion due to the guiding phenomenon: } D_{\text{gui}} = \frac{\tau_{\text{gui}}}{L \Delta\lambda} = -\frac{n_1 \Delta}{c \lambda} V \frac{d^2(VB)}{dV^2}$

(13)

For a fiber operating in the single mode regime, we study the curve $V \frac{d^2(VB)}{dV^2} = f(V)$,

with $0 \leq V \leq 2.405$, for the LP_{01} mode (see Figure 9):




Figure 9 : Curves $B=f(V)$, $d(VB)/dV$ and $V \frac{d^2(VB)}{dV^2}$ as a function of V for the fundamental mode

When considering the dispersion curves, we can note that, when V becomes lower than $2 (\lambda \uparrow)$, B rapidly decreases, thus n_e tends towards n_2 . \Rightarrow the mode spreads far in the cladding \Rightarrow attenuation.


In order to work with reduced attenuation, we are going to limit the domain of V so that $2 \leq V \leq 2,405$

for which we have $0.2 \leq V \frac{d^2(VB)}{dV^2} \leq 0.45$. For example, for $V=2.2$ $V \frac{d^2(VB)}{dV^2} \approx 0,3$

For $2.4 \leq V \leq 2.8$, the fiber is a two mode fiber but the LP_{11} mode is a leaky mode (very attenuated) and it is sometimes possible to work in these conditions of quasi single mode regime.

Comments :

- In the single mode regime, for a step index fiber, we ALWAYS have $V \frac{d^2(VB)}{dV^2} > 0$ (see fig 9), i.e. the dispersion of the guide is always NEGATIVE.
- This is in good accordance with the dispersion curves presented in chapter 2.



Indeed, in single mode regime \rightarrow long wavelengths $\rightarrow \omega$ small $\rightarrow \frac{d^2 \omega}{d \beta^2} < 0$

$$\rightarrow \frac{d^2\beta}{d\omega^2} > 0 \quad \rightarrow D_g < 0 : \text{QED (here, we do not take the material dispersion into consideration)}$$

Numerical application : $\lambda = 1.55\mu\text{m}$ $ON = 0.105$ $n_1 = 1.46$ $a = 4.5\mu\text{m}$

$$\text{thus } \Delta = \frac{ON^2}{2n_1^2} = 2.83 \cdot 10^{-3} \quad V = \frac{2\pi}{\lambda} a ON = 1.91$$

on the curve of fig 9, we read: $V \frac{d^2(VB)}{dV^2} \approx 0,45$

$$D_{\text{gui}} = - \frac{1.46 \times 2.83 \cdot 10^{-3}}{3 \cdot 10^8 \times 1.55 \cdot 10^{-6}} \times 0.6 = - 5 \cdot 10^{-6} \text{ s} / (\text{m.m}) = - 5 \text{ ps} / (\text{nm.km})$$

At $\lambda = 1.55\mu\text{m}$, $D_{\text{mat}} \approx 22 \text{ ps}/(\text{nm.km})$.

Thus, with $D_c \approx D_{\text{mat}} + D_{\text{gui}}$ we find : $D_c \approx -5 + 22 = 17 \text{ ps}/(\text{nm.km})$.

In a standard single mode fiber with a small core, (cutoff wavelength λ_c close to $1.2\mu\text{m}$), we find :

$D_{\text{gui}} (1.3\mu\text{m}) \sim -3 \text{ ps}/(\text{nm.km})$ and $D_{\text{mat}} (1.3\mu\text{m}) \sim +3 \text{ ps}/(\text{nm.km}) \rightarrow D_c \approx D_{\text{mat}} + D_{\text{gui}}$ cancel at $1.3\mu\text{m}$.

For $\lambda < 1.3\mu\text{m}$, $D_c < 0 \rightarrow$ "normal" dispersion (because it was historically observed first)

And for $\lambda > 1.3\mu\text{m}$, $D_c > 0 \rightarrow$ "anomalous" dispersion (historically observed later, but is not fundamentally "anomalous").

Discussion :

- D_{mat} depends on the material and we cannot significantly modify it : for this, manufacturers should strongly modify the concentration of dopants in the silica \rightarrow modification of the indices but also decrease of the transparency...).
- One can modify D_{gui} by modifying the guiding conditions, i.e. by changing the index profile. But one can show that, in most of the cases, D_{gui} remains < 0 (i.e. the guiding phenomenon imposes that wave packets centered at long wavelengths propagate faster than wave packets centered at shorter wavelengths).
- Thus, by adjusting D_{gui} , we can cancel the chromatic dispersion at wavelengths for which $D_{\text{mat}} > 0$, i.e. for $\lambda > 1.27\mu\text{m}$. \rightarrow It is possible to obtain $D_c = 0$ at $\lambda = 1.55\mu\text{m}$ (dispersion shifted fiber = DSF) \rightarrow It is also possible to obtain $D_c = 0$ at $\lambda = 1.3\mu\text{m}$ AND at $\lambda = 1.55\mu\text{m}$, with small D_c between the two (dispersion flattened fiber = DFF).
- To cancel the chromatic dispersion at $\lambda < 1.27 \mu\text{m}$, it is necessary to get $D_{\text{gui}} > 0 \rightarrow$ Bragg fibers, small core microstructured fibers, photonic band gap (PBG) fibers... see subsequent courses on non conventionnal optical fibers.