

Optical power measurements (1)


- ❑ The optical power measurement is fundamental for the metrology of the optical fibers: almost all the optical instruments include a power meter
- ❑ Absolute measurements: traceable to the International System of Units (SI)
 - ♦ optical sources characterization
 - ♦ characterization of optical detectors and receivers
 - ♦ safety measurements (laser safety)
- ❑ Relative measurements: not necessarily traceable measurements
 - ♦ loss/attenuation measurements
 - ♦ gain measurements
 - ♦ insertion loss measurements

Optical power measurements (2)


- ❑ The optical power measurements are commonly based on electrical power measurements.
- ❑ An optical power measured value must be traceable to the international unit of power which is defined by means of electrical quantities (electrical power reference).
- ❑ The optical power measurement can be based on thermoelectric detectors or on electronic photo-detectors.

feature	thermoelectric	electronic
dependence on wavelength	very low, wide range	very high, short range (2:1)
auto-calibration	yes	no
sensitivity	low, >10mW	very high, < 1 pW
uncertainty	down to +/-1%	down to +/-2%

Thermoelectric detectors: substitution radiometry



Thermoelectric detectors: substitution radiometry




- a) the light beam, whose power has to be measured, enters the detector
- b) at the thermal equilibrium, the temperature difference between the absorber and the thermal mass is proportional to the incident optical power:

$$\Delta T \propto P_{opt}$$

- c) this temperature difference ΔT is measured by means of a thermopile

Thermoelectric detectors




- d) the light beam is stopped with a shutter and the electrical heater is switched on
- e) the supply power of the heater is regulated in order to stabilize a new thermal equilibrium at the same temperature difference ΔT previously recorded (in step b)
- f) the electrical power P_e now supplying the heater is measured: it is the result of the measurement since we can say that


$$P_{opt} = P_e$$

the measurement is therefore based on the direct comparison between an optical power and an electrical power

p-i-n photo-detectors



- ❑ the pin photodiode is a photon-to-electron converter: the incoming photons are absorbed by the intrinsic (i) layer made by a low band-gap material
- ❑ equivalent circuit



I_L : current generated by incident light (proportional to light level)
 V_D : voltage across diode
 I_D : diode current
 C_j : junction capacitance
 R_{sh} : shunt resistance
 I' : shunt resistance current
 R_s : series resistance
 V_o : output voltage
 I_o : output current

❑ MATERIAL: Si, Ge, InGaAs



❑ Efficiency up to 90%

❑ Fast response time, bandwidth up to 100 GHz


❑ Avalanche photo-detectors (APD): lower speed (few GHz BW), higher sensitivity

p-i-n photo-detectors

□ basic circuits




PIN photodiodes




- the responsivity gives the intensity of photo-current per unit of optical power (A/W):

$$r = \frac{I}{P_{opt}} = r(\lambda) \quad \left[\frac{A}{W} \right]$$




- optical dB vs electrical dB: a change of -3 dB (halving) of the incident optical power induces a halving of the photo-current corresponding to a -6 dB variation of the electrical power at the receiver output

Spectral responsivity of photo-detectors




□ temperature dependence:

the cut-off wavelength λ
shifts of about 1 nm/K
for the InGaAs and germanium
diodes



Optical power emitted by a broadband source



□ given the source power spectral density

$$p(\lambda)$$

□ the total emitted optical power is

$$P_{TOT} = \int p(\lambda) d\lambda$$

□ given the photo-diode responsivity


$$r(\lambda)$$

□ the total photo-current is:

$$I_{TOT} = \int r(\lambda) \cdot dP = \int r(\lambda) \cdot p(\lambda) d\lambda$$

□ in case of a broadband light source we cannot directly use a photo-diode to measure the emitted total power

Relative responsivity




- the responsivity of a photo-diode is usually expressed as:

$$r(\lambda) = r(\lambda_0) \cdot \underbrace{r_{rel} f(\lambda)}_{\text{relative responsivity}} = r_{\lambda_0} \cdot r_{rel}(\lambda)$$

- the total photo-current is:

$$I_{TOT} = \int r(\lambda) \cdot dP = r_{\lambda_0} \cdot \int r_{rel}(\lambda) \cdot p(\lambda) d\lambda$$

Relative power spectral density




- we can express the source power spectral density as:

$$p(\lambda) = p(\lambda_0) \cdot \underbrace{f(\lambda)}_{\text{relative power density}} = p_{\lambda_0} \cdot f(\lambda)$$

- the total photo-current is:

$$I_{TOT} = \int r(\lambda) \cdot p(\lambda) d\lambda = p_{\lambda_0} \cdot r_{\lambda_0} \int f(\lambda) \cdot r_{rel}(\lambda) d\lambda$$

Optical power emitted by a mono-chromatic source




- the emitted optical power is concentrated only on one wavelength, therefore the total photo-current is:

$$I = \int r(\lambda) \cdot p(\lambda) d\lambda = r_{\lambda_0} \cdot r_{rel}(\lambda_s) \cdot p(\lambda_s) \cdot 1 \equiv r_{\lambda_0} \cdot r_{rel}(\lambda_s) \cdot P_{TOT}$$

- by measuring I , we obtain: $P_{TOT} = \frac{I}{r_{\lambda_0} \cdot r_{rel}(\lambda_s)}$

Optical power emitted by a LED



$$P_{LED} = \int p_{\lambda_s} \cdot f(\lambda) d\lambda = p_{\lambda_s} \cdot \int f(\lambda) d\lambda$$


- ❑ the emitted optical power is spread over a wavelength range around λ_s , where the responsivity is not constant
- ❑ the total photo-current is:

$$I = \int r(\lambda) \cdot p(\lambda) d\lambda = r_{\lambda_0} \cdot p_{\lambda_s} \cdot \int r_{rel}(\lambda) \cdot f(\lambda) d\lambda =$$

$$= r_{\lambda_0} \frac{P_{LED}}{\int f(\lambda) d\lambda} \int r_{rel}(\lambda) \cdot f(\lambda) d\lambda$$

- ❑ by measuring I , we obtain: $P_{LED} = \frac{I}{r_{\lambda_0}} \frac{\int f(\lambda) d\lambda}{\int r_{rel}(\lambda) \cdot f(\lambda) d\lambda}$

Optical power emitted by a LED



$$P_{LED} = \int p_{\lambda_S} \cdot f(\lambda) d\lambda = p_{\lambda_S} \cdot \int f(\lambda) d\lambda$$


$$\square P_{LED} = \frac{I}{r_{\lambda_0}} \frac{\int f(\lambda) d\lambda}{\int r_{rel}(\lambda) \cdot f(\lambda) d\lambda}$$

□ if *a)* the emission spectrum is symmetric and *b)* the responsivity linearly changes with λ , then we can proceed as with a laser source:

$$P_{LED} = \frac{I}{r_{\lambda_0} \cdot r_{rel}(\lambda_s)} \quad (1)$$

□ normally we have to apply a correcting factor to the value given by relation (1)

Power meters with photo-detectors



❑ accurate power measurements only when:

- ♦ an individual correction for each wavelength is applied
- ♦ the temperature is well stabilized
- ♦ the photo-detector has a good spatial homogeneity
- ♦ reflections are minimized
- ♦ a low polarization dependence is guaranteed

Non-linearity of the power meters

- ❑ a photo-detector has a typical dynamic of six or more decades
- ❑ detector nonlinearities
 - ◆ noise effect at the lowest levels of the optical power
 - ◆ supra-linearity at the medium power levels
 - ◆ saturation at high power levels
- ❑ electronic nonlinearities
 - ◆ offset of the amplifier at low power levels
 - ◆ saturation of the amplifier at high power level
 - ◆ ranging discontinuities due to the non-matching amplifier gains


cont.


Photo-detector noise

- the current noise can be represented as noise equivalent (optical) power (NEP):


$$NEP = \frac{1}{r} \sqrt{[i_n^2]} = \frac{1}{r} \sqrt{2eB_n(2I_{dark} + r \cdot P_{opt})} \quad \left[\frac{W}{\sqrt{Hz}} \right]$$

where: R is the responsivity, I_{dark} is the dark current, B_n is the noise equivalent bandwidth, and P_{opt} is the incoming optical power

- $SNR = \frac{P_{opt}}{NEP}$




Absolute optical power measurements



- ☐ production tests
- ☐ for the highest power levels ($> 100 \text{ mW}$) it is necessary to insert an attenuator to avoid the photo-detector damage
- ☐ when the light source has a wide emission spectrum, since the detector responsivity is a function of λ , the power meter reading could need a correction

Power meter calibration



- ❑ we must have a photo-detector traced to international standard units
- ❑ the responsivity curve is constructed point by point

Uncertainty of the optical power measurement

- ❑ Fluctuations of the power of the testing laser source: the main cause can be related to the high sensitivity to optical feedback. The inaccuracy can be very high if no caution is used.
- ❑ Power meter calibration (see the user manual and the calibration certificate of the instrument): the best instruments declare an accuracy of $\pm 2\%$.
- ❑ Systematic errors:
 - ◆ short knowledge of the spectral characteristic of the optical source
 - ◆ the geometry of the real light beam is different from the specified one