

About Sellmeier relation and the calculation of the material dispersion :

See : https://en.wikipedia.org/wiki/Sellmeier_equation

See also : https://www.rp-photonics.com/sellmeier_formula.html

Sellmeier equation

From Wikipedia, the free encyclopedia

The **Sellmeier equation** is an [empirical relationship](#) between [refractive index](#) and [wavelength](#) for a particular [transparent medium](#). The equation is used to determine the [dispersion](#) of [light](#) in the medium.

It was first proposed in 1872 by Wilhelm Sellmeier and was a development of the work of [Augustin Cauchy](#) on [Cauchy's equation](#) for modelling dispersion.^[1]

Contents [hide]

- 1 [The equation](#)
- 2 [Coefficients](#)
- 3 [See also](#)
- 4 [References](#)
- 5 [External links](#)

The equation [\[edit \]](#)

In its original and the most general form, the Sellmeier equation is given as

$$n^2(\lambda) = 1 + \sum_i \frac{B_i \lambda^2}{\lambda^2 - C_i},$$

where n is the refractive index, λ is the wavelength, and B_i and C_i are experimentally determined *Sellmeier coefficients*. These coefficients are usually quoted for λ in [micrometres](#). Note that this λ is the vacuum wavelength, not that in the material itself, which is λ/n . A different form of the equation is sometimes used for certain types of materials, e.g. [crystals](#).

Each term of the sum representing an [absorption](#) resonance of strength B_i at a wavelength $\sqrt{C_i}$. For example, the coefficients for BK7 below correspond to two absorption resonances in the [ultraviolet](#), and one in the mid-[infrared](#) region. Close to each absorption peak, the equation gives non-physical values of $n^2 = \pm\infty$, and in these wavelength regions a more precise model of dispersion such as [Helmholtz's](#) must be used.

If all terms are specified for a material, at long wavelengths far from the absorption peaks the value of n tends to

$$n \approx \sqrt{1 + \sum_i B_i} \approx \sqrt{\epsilon_r},$$

where ϵ_r is the relative [dielectric constant](#) of the medium.

For characterization of glasses the equation consisting of three terms is commonly used:^{[2][3]}

$$n^2(\lambda) = 1 + \frac{B_1 \lambda^2}{\lambda^2 - C_1} + \frac{B_2 \lambda^2}{\lambda^2 - C_2} + \frac{B_3 \lambda^2}{\lambda^2 - C_3},$$

As an example, the coefficients for a common [borosilicate crown glass](#) known as *BK7* are shown below:

Coefficient	Value
B ₁	1.03961212
B ₂	0.231792344
B ₃	1.01046945
C ₁	6.00069867×10 ⁻³ μm ²
C ₂	2.00179144×10 ⁻² μm ²
C ₃	1.03560653×10 ² μm ²

The Sellmeier coefficients for many common optical materials can be found in the online database of [RefractiveIndex.info](#)[☞].

For common optical glasses, the refractive index calculated with the three-term Sellmeier equation deviates from the actual refractive index by less than 5×10⁻⁶ over the wavelengths' range^[4] of 365 nm to 2.3 μm, which is of the order of the homogeneity of a glass sample.^[5] Additional terms are sometimes added to make the calculation even more precise.

Sometimes the Sellmeier equation is used in two-term form:^[6]

$$n^2(\lambda) = A + \frac{B_1 \lambda^2}{\lambda^2 - C_1} + \frac{B_2 \lambda^2}{\lambda^2 - C_2}.$$

Here the coefficient A is an approximation of the short-wavelength (e.g., ultraviolet) absorption contributions to the refractive index at longer wavelengths. Other variants of the Sellmeier equation exist that can account for a material's refractive index change due to [temperature](#), [pressure](#), and other parameters.

Coefficients [[edit](#)]

Table of coefficients of Sellmeier equation^[7]

Material	B ₁	B ₂	B ₃	C ₁ , μm ²	C ₂ , μm ²	C ₃ , μm ²
borosilicate crown glass (known as <i>BK7</i>)	1.03961212	0.231792344	1.01046945	6.00069867×10 ⁻³	2.00179144×10 ⁻²	103.560653
sapphire (for ordinary wave)	1.43134930	0.65054713	5.3414021	5.2799261×10 ⁻³	1.42382647×10 ⁻²	325.017834
sapphire (for extraordinary wave)	1.5039759	0.55069141	6.5927379	5.48041129×10 ⁻³	1.47994281×10 ⁻²	402.89514
fused silica	0.696166300	0.407942600	0.897479400	4.67914826×10 ⁻³	1.35120631×10 ⁻²	97.9340025
Magnesium fluoride	0.48755108	0.39875031	2.3120353	0.001882178	0.008951888	566.13559

For pure silica (SiO₂), which is the material used for manufacturing most of the optical fibers, the Sellmeier relation is

$$n^2 - 1 = \frac{0.6961663\lambda^2}{\lambda^2 - 0.0684043^2} + \frac{0.4079426\lambda^2}{\lambda^2 - 0.1162414^2} + \frac{0.8974794\lambda^2}{\lambda^2 - 9.896161^2}$$

Let us note that :

- 1- the above relation is also called "dispersion formula".
- 2- The phase velocity is $v_\varphi = \frac{c}{n}$. In guided optics, $v_\varphi = \frac{\omega}{\beta}$
- 3- The group index is $n_g = n - \lambda \frac{dn}{d\lambda}$ and the group velocity is $v_g = \frac{c}{n_g}$. In guided optics, $v_g = \frac{d\omega}{d\beta}$
- 4- the derivative $dn/d\lambda$ is often called "chromatic dispersion".
- 5- Furthermore, as shown in the provided written course of chapter 4, the quantity $\frac{d^2\beta}{d\omega^2} = \frac{d(\frac{1}{v_g})}{d\omega}$ is called "group velocity dispersion = GVD", while it is rather a quantity corresponding to a group time delay dispersion (the group time delay t_g over a length of propagation L being related to v_g by $v_g = \frac{L}{t_g} \Rightarrow t_g = \frac{L}{v_g}$).

From the above relations, one can easily show that $\frac{d^2\beta}{d\omega^2} = \frac{1}{c} \frac{dn_g}{d\omega} = \frac{\lambda^3}{2\pi c^2} \frac{d^2n}{d\lambda^2}$. This quantity can be expressed in s²/m or in fs²/mm

- 6- Finally, the chromatic material dispersion is $D = D_{mat} = \frac{1}{L} \frac{dt_g}{d\lambda} = -\frac{\lambda}{c} \frac{d^2n}{d\lambda^2}$. It is expressed in s/(m.m) or ps/(nm.km).
- 7- From 5 and 6, we easily see that the relation between the GVD $\frac{d^2\beta}{d\omega^2}$ and the chromatic dispersion D is : $\frac{d^2\beta}{d\omega^2} = -\frac{\lambda^2}{2\pi c} \cdot D$

On the following internet site, one can easily find the curve $n = f(\lambda)$ for different materials, and in particular for pure silica :

<https://refractiveindex.info/?shelf=main&book=SiO2&page=Malitson>

On this page, one can obtain the refractive index at a given wavelength, the derivative $dn/d\lambda$, the group index, the GVD and the chromatic dispersion, at this wavelength.